

Process-related data display example

Status: Wait for input

Active Order no.:

Start time:

Time to end:

Alarm

PW_CarbonPot — SW_CarbonPot

Batch input

Customer:

Order number:

Shop order number:

Furnace No.:

Carbon in core:

Alloy factor

Controller

PC

Operator:

Comment

Start time:

End time:

Diffusions - Diagram

Batch input
Batch report

SW_CarbonPot	0.00 %	beobachtetgr. Osmittelpunkt	11.07.2007 21:21:48
Start	0	good	11.07.2007 21:21:48
Diff-Start	0	good	11.07.2007 21:21:48
Ende	1	good	11.07.2007 21:21:48
Legierung	1.10	good	11.07.2007 21:21:48
Restzeit	0.00 h	good	11.07.2007 21:21:48